



## DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 26L: Climb straight ahead and track 256°. Thence...

ARE 3W: At 4.5 NM DME BG, turn right to GU NDB. At GU intercept and follow ARE R-293 (113°) to ARE VOR.

DIN 3W: At 4.5 NM DME BG, turn right to track 020° to intercept and follow GUR R-241 (061°) to PELIK then intercept and follow DIN R-280 (100°) to DIN VOR/DME.

DIN 3X: At 4.5 NM DME BG, turn right to GU NDB. At GU intercept and follow DIN R-270 (090°) to DIN VOR/DME.

GUR 3W: At 4.5 NM DME BG, turn right to track 020° to intercept and follow GUR R-241 (061°) to PELIK then to GUR VOR/DME.

MATER 3W: At 4.5 NM DME BG, turn right to track 300° to intercept and follow GU 270° to MATER.

QPR 3W: At 4.5 NM DME BG, turn right to GU NDB. When intercepting QPR R-358, turn right to intercept and follow QPR R-003 (183°) to QPR VOR/DME.

SOMEN 3W: At 4.5 NM DME BG, turn right to RB001, turning point abeam, then intercept and follow the route (RB001-SOMEN) to SOMEN, turning point to overfly.